



## HandJet EBS-260 Cleaning Maintenance

### Clean the nozzle faceplate

- As needed, use the washup fluid in the atomizer bottle to clean the printer face, and guide rollers to remove the remnants of ink and dirt after usage.

### Acetone Based Ink – Black MEK or Black Acetone

- Daily
  - The nozzle plate face should be sprayed with washup fluid (until all ink and debris are removed. Use a foam-tipped swab or lint free cloth to help with removal.)
- Every two days
  - Purge the unit of ink with cleaning fluid

### Periodic Purging (**read through all steps before starting**)

- Power down the printer
  - Remove the ink cartridge
  - Install a cleaning cartridge
  - Turn the printer on & press 'Start' to begin pressurization
  - Wait for pressurization to finish, press 'Stop'
- Ensure adequate ventilation in the area
- Press & hold the "Start" icon in lower right of display
  - Press the "Purge" icon
    - *Point the unit downward into a hazmat-type container or scrap cardboard*
    - Press and hold the trigger
    - The unit will beep and FIRE ALL 32 NOZZLES
  - After 30-40 seconds of purging, you should see the Black jets turn clear as the ink is replaced by cleaning fluid
- Once the jets look clear, release the trigger
- Power down the unit
- Loosen the cleaner cartridge to remove pressure in the system, then tighten the cleaner cartridge to prevent dust, dirt or air from entering the back of the unit.

### Restarting the unit for printing

- Following the same procedure as above
  - With the ink cartridge connected – purge until the clear ink becomes black.